

ASSEMBLY AND INSTRUCTION MANUAL MODEL 0001 FUNKI

© 2009 KURT BEIER & KATI QUINGER









www.bullfrog-design.com



FUNKI - how it works:



1. Take the cushion at its upper side and put the cushion on your knees with the zipper on the bottom. The seamless side faces you.



2. Move the upper part of the cushion towards yourself until the final position is reached.



3. Now you are able to move the upper part backwards until the upper part of the cushion will click into place in the zero position.



4. Now put the cushion in the preferred position (e.g. in the back, seamless side at the front and zipper at the bottom). You are able to choose different locking positions depending on your preference and position by slowly pulling the upper part of the cushion towards yourself.

Keep all documents relating to the purchase of your furniture carefully, even beyond the legal warranty period of 2 years. You will find all important information in your product folder and also on our website *www.bullfrog-design.com*