

ASSEMBLY AND INSTRUCTION MANUAL MODEL 1070 IWAN

© 2016 KURT BEIER & KATI QUINGER





Flexibly placeable back in different sizes



High-quality and soft sitting comfort




With the opportunity to place individual, whether single or as living area




Use of back function, functional back, Moba:

Adjustment of back slant:


1. To adjust the desired position grip the back from the outside and pull it carefully towards yourself.




2. To obtain zero position pull the back carefully beyond the top position towards yourself and fold down into zero position (horizontal).



3. From zero position you can easily snap the back into desired position.





To adjust the upper back of model type 610, proceed the same way.






Element connectors

Attention!

Only at furnitures where connectors are pre-assembled (for an extra charge).



- 1. Turn connector ratchet 1 of element A to the outside.
- 2. Firmly push together part A and B, until metal guides 2 catch into guides 1.
- 3. In case of dismounting lift part B with the metal guides 2 and pull away.