

ASSEMBLY AND INSTRUCTION MANUAL

MODEL OD5728 CASINO

© 2017 KURT BEIER & KATI QUINGER



Casual chair with functional back,
optionally with or without amrest



Comfortable bench,
without amrest




Matching, planked
solid wood dining table


Use of back function

1. Adjustment of back slant:

To adjust the desired position grip the back from the outside and pull it carefully towards yourself.



2. To obtain zero position pull the back carefully beyond the top position towards yourself and fold down into zero position.



3. From zero position you can easily snap the back into desired position.

ATTENTION! DON'T SIT DOWN ON BACK!