bullfrog®

PRODUCT INFORMATION MODEL 6022 DODO

© 2017   KURT BEIER & KATI QUINGER

FUNKI - FUNCTIONAL CUSHION
WITH USEFUL PLUG-IN BRACKET

COMFORTABLE
PLUG-IN HEAD ROLL

DECORATIVE BOX PLEAT

DODO: A COMFORTABLE SLEEPING PROGRAMME WITH FUNCTIONAL CUSHION AND PLUG-IN HEAD ROLL FOR A FLEXIBLE DESIGN IN YOUR BEDROOM. THE PROCESSING IN DETAIL OF BOX PLEAT AND OVERCAST SEAM (FABRIC) OR RAW EDGED WORKMANSHIP (LEATHER) GIVES DODO A VERY MODERN LOOK. THE INSERT DEPTH OF SLATTED FRAME IS ADJUSTABLE, THUS THE HEIGHT OF MATRESS CAN BE PROPERLY ADJUSTED. THIS BED IS ALSO SUITABLE FOR BOX SPRING SYSTEMS.

Insert depth for slatted frame: approx. 21,5-31 cm
Insert depth for box spring frame: approx. 21,5-31 cm
(measured from top edge of bed frame)

Processing options of main seam / decorative seam

	Plain seam	Lap seam	Raw edged	Moccasin seam extra charge	Twin seam extra charge	KR* (zipper piping) extra charge	Overcast seam extra charge	Piping	Two needle seam	Square seam extra charge
Fabric							x			
Leather			x							

It is possible to order main seam or decorative seam either tone in tone like the colours of cover or in the contrasting colours white, nature, grey, rust and black. On request spezial colours possible.
Zipper piping: optionally in the colours black, red, nature or light grey.

Processing options

|	Raw edged	Overcast seam	Box pleat
Fabric		x	x
Leather	x		x

It is possible to order main seam or decorative seam either tone in tone like the colours of cover or in the contrasting colours white, nature, grey, rust and black. On request spezial colours possible.

8 200 8

approx. 102

approx. 45 | approx. 72

Side view (Beds + Funki S 578 + Roll M 652)

□ = Label

Functional bed

8 · 216 · 200 · 8

8 140 8
156

Bed 140 cm
B14

8 · 216 · 200 · 8

8 160 8
176

Bed 160 cm
B16

8 · 216 · 200 · 8

8 180 8
196

Bed 180 cm
B18

8 · 216 · 200 · 8

8 200 8
216

Bed 200 cm
B20

Consistend with back of 1070

60

Side view

70

23

Side view, folded down

Moba B
Functional back
(tapered cushion)
80 x 70
611

Moba XB
Functional back
(tapered cushion)
95 x 70
612

☐ = Label

Cushions:
Fabric: overcast seam, either tone in tone or in contrasting colours possible!
Leather: raw edged, either tone in tone or in contrasting colours possible!

ca. 20

Funki S
Functional cushion
(tapered cushion)
(with bracket)
(fabric: overcast seam)
(leather: raw edged)
62 X 78
578

ca. 24

Roll M
to plug in
(fabric: overcast seam)
(leather: raw edged)
∅=30 L=75
652

Decoration blanket
126 x 202
D30

Fitted sheets (fabric):

Fitted sheets for type B14: **SP14** (140x200 cm)
Fitted sheets for type B16: **SP16** (160x200 cm)
Fitted sheets for type B18: **SP18** (180x200 cm)
Fitted sheets for type B20: **SP20** (200x200 cm)

Replacement cover with box pleat (fabric/leather):

Complete slip cover for type B14: **H14**
Complete slip cover for type B16: **H16**
Complete slip cover for type B18: **H18**
Complete slip cover for type B20: **H20**

Each piece of furniture is handmade and unique. Deviations to the listed measurements may be caused by:
1. different upholstery materials (fabric, leather), 2. processing of ticking mats, 3. the preasure to combine individual parts, etc.
The seat comfort of a sofa type with larger seat depth usually differs from one with lower depth.

## Matching slide table 1117, solid wood (available in different wood types):

60
48
43,5

Side view
(type 866)

60
35

Table
to push
866

Combination of exhibition:

Schiebe-
tisch

Einsteckrolle

Einsteckrolle

- Type B16
- 2x type 652
- Type 578
- Type 866

Each piece of furniture is handmade and unique. Deviations to the listed measurements may be caused by:
1. different upholstery materials (fabric, leather), 2. processing of ticking mats, 3. the preasure to combine individual parts, etc.
The seat comfort of a sofa type with larger seat depth usually differs from one with lower depth.

FUNKI - how it works:

EN: 1. Move the upper part of the cushion towards yourself until the final position is reached.

EN: 2. Now you are able to move the upper part backwards until the upper part of the cushion will click into place in the zero position.

EN: 3. Now put the cushion in the preferred position (e.g. in the back, seamless side in front and zipper at the bottom). By pulling the upper part of the chushion towards yourself, you are now able to choose among 16 raster positions, however you like it.

Use of back function, functional back, Moba:

Adjustment of back slant:
1. To adjust the desired position grip the back from the outside and pull it carefully towards yourself.

2. To obtain zero position pull the back carefully beyond the top position towards yourself and fold down into zero position (horizontal).

3. From zero position you can easily snap the back into desired position.